



We serve the solution

Read more →

TC Soft Cloud -

Simple and reliable documentation of all your HACCP data

www.temp-rite.eu

temp-rite









We serve the solution

More and more HACCP requirements are constantly emerging in all customer segments. With our TC Soft Cloud, we are offering an innovative monitoring and regulating instrument that will enable you to keep a tight control on compliance with, and documentation of, all your HACCP requirements - simply, reliably and methodically.

See for yourself the advantages of our TC Soft Cloud solution.

There are plenty of good reasons for using the TC Soft Cloud. Here are the main advantages:



Location-independent access to every* cart/trolley in your fleet



No restrictions on the hardware or software you use. Access to data is obtained via a standard browser



The TC Soft Cloud is compatible with desktop PCs, tablets and smartphones



The intuitive user interface guarantees maximum acceptance on the part of users



High degree of data reliability and security compared with local-workplace solutions



Remote diagnostics facilitate support process



Monitoring in real time – deviations from predefined procedures are flagged without delay

 $^{^{\}ast}$ Temp-Classic Pro, Temp-Contact, Dock-Rite Pro and Temp-Serve

temp-rite

How the TC Soft Cloud functions

Each system sends data via a WLAN or a LAN connection direct to the Cloud. A gateway software package is required for the exchange of data between the carts/trolleys and the Cloud.

Available for the following systems:

Temp-Contact

Temp-Serve



Temp-Classic Pro



Dock-Rite Pro







(dependent on the model)



Gateway

software

The software is installed in an internet-capable workstation. This is required for LAN- and WLAN-based transfer of data to the Cloud

HACCP TC Soft Cloud software



Access



Customer's PC, tablet or smartphone

temp-rite

How the TC Soft Cloud is used

- The TC Soft Cloud package is licensed software. A licence, which is valid for 2 years, is required for each unit operated by the customer
- Each customer receives a three-level access-rights system for the use of the software. The three levels (customer manager user) define given sets of rights. Each person sees only what is relevant to his/her duties and activities.
- Login is by means of a user name and a password entered via a browser
- All the carts/trolleys registered in the Cloud are displayed on the dashboard. An intuitive navigation-and-software interface guarantees high acceptance rates with users.



TC Soft Cloud data-transfer options



Application, test and contract-signing phase

Application analysis

- Tests to establish which systems the TC Soft Cloud can be used with (pre-existing systems, new systems)
- Systems already being used can be retrofitted with the necessary modules (testing is in this case essential)

Technical checks

- Checks to establish that all the technical pre-requirements for use of the TC Soft Cloud have been met
- We recommend the involvement of, and direct communication between, temp-rite's and the customer's own IT specialists

Signing of the contract

- The use of the TC Soft Cloud software package is subject to a licence agreement. For reasons connected with data-protection and privacy law, this agreement will involve the drawing up of a contract covering:
 - supply of the software
 - data protection and an end user licence agreement (EULA)
 - licensing of the cart/trolley for 2 years

Implementation phase

Granting of the licence, adding systems to the cloud, customer training

- The assignment of contracts to carts/trolleys in the customer's fleet is undertaken by temp-rite
- temp-rite sets up the customer's account and provides training for selected managers (key users)
- Easy-to-follow instructional videos explain all of the main system functions. These how-to videos remain available for reference and for post-implementation instruction of further employees



Example of one of the available how-to videos

an Ali Group Company The Spirit of Excellence

Germany & Luxembourg

temp-rite International GmbH Theodor-Barth-Str. 29 D-28307 Bremen Phone: +49 (0) 4 21-4 86 92-0 E-Mail: info@temp-rite.de

The Netherlands

temp-rite International Holding B.V. Weidehek 64 NL-4842 AS Breda Phone: +31 (0) 76-5 42 43 43 E-Mail: info@temp-rite.nl

Belgium

temp-rite International Gemeenteplaats 31 BE-2960 Brecht Phone: +32 (0) 3-3 15 94 65 E-Mail: info@temp-rite.be

Hungary

temp-rite International Kft. Krisztina Krt. 83-85 H-1016 Budapest Phone: +36 (0) 1 212-70 43 E-Mail: sk@temprite.t-online.hu